

CARE & MAINTENANCE OF EX-CELL KAISER PRODUCTS

CONGRATULATIONS ON YOUR PURCHASE OF AN EX-CELL KAISER PRODUCT! WITH A LITTLE CARE AND MAINTENANCE, YOU WILL FIND YOUR EX-CELL KAISER PRODUCT WILL RETAIN ITS ATTRACTIVE FINISH AND PROVIDE YOUR FACILITY WITH YEARS OF LOYAL SERVICE.

POWDER COATED PRODUCTS

Our powder-coated products are easy to care for and with just some gentle, regular cleaning, feature durable powder coated finishes that should last a lifetime.

Wipe up any spills or splashes immediately using a damp (not wet) soft cloth. Follow with a dry soft cloth. If needed, use only a mild, non-abrasive soap, such as a dishwashing liquid on a damp, soft cloth.

Never scrub the surface of your Ex-Cell product and never use anything that might scratch the surface, such as a wire brush or scrubbing sponge. Treat the surface of your Ex-Cell product with the same care as you would the finish of a car.

Wiping the units down with a soft, damp cloth regularly will keep your finish looking clean and vibrant.

STAINLESS STEEL PRODUCTS

Stainless steel, an alloy of iron that contains ten percent chromium, is a very resilient material used in a wide range of household and industrial products. It's resistant to <u>rust</u> and tarnish due to the chromium film on its surface. Not only is stainless steel used in household products, it's also used in wide variety of architectural structures on account of its strong resistance to corrosion that can be caused by changes in atmospheric conditions What may appear to be rust is caused by iron particles on the surface of the stainless steel. Despite its name, stainless steel can, and does stain, and requires regular cleaning and maintenance.

The first thing to consider when you set out to clean stainless is *what not to do*. Some popular cleaning products will damage the finish on stainless steel, and even plain water can leave unsightly marks and spots if not used properly.

- DON'T use chlorine bleach or any product containing chloride.
- DON'T use oven cleaners.
- DON'T use <u>steel wool</u>, steel brushes, or highly abrasive scrubbing pads—these can cause scratches or leave a residue of small particles that may rust.
- DON'T use abrasive cleansers on brushed stainless steel.
- DON'T clean a stainless steel surface unless it is cool to the touch.
- DON'T use gritty, dirty, or excessively hard water, as it can leave spots or brownish stains.

Care & Maintenance of Ex-Cell Kaiser Products Updated January 1, 2025 Page 2

One of the best habits to adopt is to wipe down your unit on a regular basis with a damp, soapy washcloth at least once a week; rinse the washcloth with clean water and wipe again to remove any soap; then finish with a wipe of a dry terry towel.

Always wipe in the direction of the stainless steel "grain," starting at the top of the unit and working your way down towards the floor.

For heavier dirt and stains, use a mild detergent, and hot water. Be sure to rinse the surface and towel dry to prevent water spots or staining.

To remove really tough dirt and stains, make a paste of baking soda mixed with liquid dish soap and gently scrub with soft cloth or an old toothbrush. If some stains remain, use undiluted vinegar, again scrubbing gently with a soft brush. Be sure to rinse and towel dry.

You may want to buff your units periodically with a stainless steel polish, lemon oil, or a siliconebased spray to maintain a lustrous finish. Apply the polish in the direction of the grain with a lint-free cloth; buff and dry with another lint-free cloth.

There are numerous non-abrasive cleaners and polishes that are designed specifically for use on stainless steel. 3M professional grade, Bar Keeper's Friend, Cerama Bryte, Sprayway and Weiman. When in doubt, always test your cleaner on someplace hidden, like the back or sides, before moving on to the front or top.